


# 6 DRAWER CHEST

Stock number: 3052-76


Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



## Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

## Necessary Tools :



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.


This product takes approximately **5 MINUTES** to assemble with **2 PEOPLE**.

All assembly should be performed on a flat, stable, clean and soft surface.


This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product

The fitting pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

**IMPORTANT:** Retain these instructions for future reference.



## Fittings and parts checklist

Item	Description	Qty.	Item	Description	Qty.
1	Top unit	x 1	A	Felt Ø20x6mm 	x 8

# Step By Step Assembly Instructions

## Step

1

1.1 : Lay all parts on a flat, stable, clean and soft surface.


1.2 : Remove the plastic from 8x felts (A) and stick felts (A) onto under top unit (1) as shown.

1.3 : Stand the unit upright

Fitting




A x 8




# UNDERMOUNT DRAWER GLIDE ADJUSTMENT INSTRUCTION

## ASSEMBLE



Lay the drawer bottom onto the slide then push the drawer into the cabinet



## HEIGHT ADJUSTMENT




Turn clockwise to lift up



Turn counterclockwise to down

## REMOVE



For removal, extend the runner all the way out. Unlock by hold the handle and pull out the drawer.

