


ARMCHAIR - POWER RECLINER

Stock number: U25-95X-SCM

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Tools :



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.


This product takes approximately 20 MINUTES to assemble with 2 PEOPLE.

All assembly should be performed on a flat, stable, clean and soft surface.


This product is HEAVY, it should be assembled as near as possible to the point of use. TAKE CARE WHEN LIFTING to avoid personal injury and (or) damage to the product.

The fitting pack contains SMALL ITEMS which should be KEPT AWAY FROM YOUNG CHILDREN.

IMPORTANT: Retain these instructions for future reference.



2




1

Fittings and parts checklist


Item	Description	Qty.	Item	Description	Qty.
1	Seat unit without backrest.	x 1			
2	Backrest	x 1			
A	 x 1	x 1			

Step By Step Assembly Instructions

- Step 1**
- 1.1: Locate the mounting bracket on the back of the seat unit and the corresponding slots on the backrest panel.
 - 1.2: Align the backrest with the seat unit and slide it down vertically until it is fully seated.
- Ensure a "click" is heard. This sofa uses a slot-and-tab system, and the "click" confirms that the backrest has been installed correctly.



- Step 2**
- 2.1: Remove the plug from the mechanism at the bottom of the armchair.




Step By Step Assembly Instructions


Step 3

3.1: Connect the power cable to the mechanism underneath the armchair.

3.2: Plug the power cable into the nearest suitable power outlet. The cable length is 2000mm, so please ensure the armchair is positioned close enough to the socket and that the cable is not stretched, trapped or caught in the mechanism.




Ax1



Step 4

4.1: Press and hold the button on the armrest to extend the recliner. Press and hold the button in the opposite direction to retract the recliner.



Step 4

4.1 : Final assembly checks

- Please ensure that all fixings are fully tightened and that the back cushions are securely located before using the armchair.

Care and maintenance information

4.2 : How to Care for Your Upholstered Furniture

Routine Cleaning

- Vacuum or lightly brush regularly to remove dust and dirt.
- Rub very gently to avoid changing the fabric colour.

Avoid

- Prolonged exposure to direct sunlight, which may cause fading.
- Placement near heat sources (e.g., radiators or open flames).

Spills

- Act quickly. Blot excess liquid using a white paper towel.
- Dab gently with a clean towel. Avoid soaking the material.

