


# HAMPSTEAD TRIPLE WARDROBE

Stock Number: 8005-83

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.




## Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

## Necessary Tools



(Included)



A cross head screwdriver only should be used to assemble this product, an electric drill may cause damage to the product and is not recommended.

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product takes approximately **60 MINUTES** to assemble with **2 PEOPLE**.

























All assembly should be performed on a flat, stable, clean and soft surface.


This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product

The fitting pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

**IMPORTANT:** Retain these instructions for future reference.

# Fittings and parts checklist Triple Wardrobe Top


Item	Description	Qty.	Item	Description	Qty.
1	Top panel	x 1	9	Top back rail	x 1
2	Left side panel	x 1	10	Bottom front rail	x 1
3	Right side panel	x 1	11	Bottom back rail	x 1
4	Partition	x 1	12	Left vertical rail	x 1
5	Left door	x 1	13	Fixed shelf	x 1
6	Right door	x 2	14	Adjustable shelf	x 3
7	Top rail	x 1	15	Back panel	x 3
8	Top front rail	x 1	16	Right vertical rail	x 1
A	SV fitting system dowel	 x 4	N	Hex head bolt M6x20mm	 x 12
B	SV fitting system grub screw	 x 4	O	Round head bolt M4x30mm	 x 3
C	Cam screw	 x 14	P	Varianta head screw Ø4.2x10.5mm	 x 8
D	Cam lock	 x 14	Q	Round head screw Ø4x15mm	 x 66
E	Dowel Ø8x30mm	 x 16	R	Round head screw Ø4x25mm	 x 4
F	Cloth bar support	 x 4	S	Round head screw Ø4x30mm	 x 6
G	Short cloth bar	 x 1	T	Hex key	 x 1
H	Long cloth bar	 x 1	U	Hinge cover cap	 x 9
J	Wood shelf support	 x 12	V	Mounting plate	 x 2
K	Knob	 x 3	W	Nylon strap	 x 1
L	Hex head bolt Ø7x38mm	 x 2	Y	Flat head screw Ø4x15mm	 x 2
M	Hex head bolt Ø7x50mm	 x 3	Z	Flat head screw Ø4x25mm	 x 2



# Step By Step Assembly Instructions

- Step 1**
- 1.1 : Lay all parts on a flat, stable, clean and soft surface.
  - 1.2 : Attach 4x cam screws (C) into the pre-drilled holes on left side panel (2) as shown. Use a screwdriver to turn fitting (C) clockwise to fix.
  - 1.3 : Attach 1x dowels (E) into the pre-drilled hole on the left side panel (2) as shown.
  - 1.4 : Attach 1x cloth bar support (F) onto left side panel (2) using 2x varianta head screws (P) as shown. Use a screwdriver to turn fitting (P) clockwise to fix.

Fitting



C x 4




E x 1



F x 1




P x 2



# Step By Step Assembly Instructions

- Step 2**
- 2.1 : Attach 6x cam screws (C) into the pre-drilled holes on right side panel (3) as shown. Use a screwdriver to turn fitting (C) clockwise to fix.
  - 2.2 : Attach 1x dowels (E) into the pre-drilled hole on right side panel (3) as shown.
  - 2.3 : Attach 1x cloth bar support (F) onto right side panel (2) using 2x varianta head screws (P) as shown. Use a screwdriver to turn fitting (P) clockwise to fix.

## Fitting



C x 6




E x 1



F x 1




P x 2




# Step By Step Assembly Instructions

- Step 3**
- 3.1 : Attach 2x cam screws (C) into the pre-drilled holes on partition (4) as shown. Use a screwdriver to turn fitting (C) clockwise to fix.
  - 3.2 : Attach 3x dowels (E) into the pre-drilled hole on partition (4) as shown.
  - 3.3 : Attach 2x cloth bar supports (F) onto partition (4) using 4x varianta head screws (P) as shown. Use a screwdriver to turn fitting (P) clockwise to fix.




- Step 4** : Attach 4x SV fitting system dowels (A) into top panel (1) by screwing fitting (A) into the inset fittings that are located inside top panel (1) as shown. Ensure the direction of the holes on fittings (A) are facing correctly as per diagram. Use a screwdriver to turn fitting (A) clockwise to fix.



# Step By Step Assembly Instructions


- Step 5**
- 5.1 : Attach 2x dowels (E) into the pre-drilled holes on top rail (7) as shown.
  - 5.2 : Attach 2x dowels (E) into the pre-drilled holes on top front rail (8) as shown.
  - 5.3 : Attach 2x dowels (E) into the pre-drilled holes on top back rail (9) as shown.
  - 5.4 : Attach 2x dowels (E) into the pre-drilled holes on bottom front rail (10) as shown.
  - 5.5 : Attach 2x dowels (E) into the pre-drilled holes on bottom back rail (11) as shown.
  - 5.6 : Attach 2x dowels (E) into the pre-drilled holes on fixed shelf (13) as shown.

Fitting




# Step By Step Assembly Instructions

**Step 6** : Attach top back rail (9) and bottom back rail (11) onto vertical rail (12) and (16) as shown. Ensure plastic dowels are aligned correctly with the holes of mating parts before attaching.



**Step 7** 7.1 : Attach top rail (7) onto top panel (1) as shown. Ensure dowels (E) are aligned correctly with the holes of mating parts before attaching.  
7.2 : Secure top rail (7) to top panel (1) using 6x round head screws (S) as shown. Use a screwdriver to turn fitting (S) clockwise to fix.


Fitting





# Step By Step Assembly Instructions

- Step 8**
- 8.1 : Attach partition (4) onto vertical rail (16) as shown. Ensure dowels (E) are aligned correctly with the holes of mating parts before attaching.
  - 8.2 : With help of an assistant stand the structure assembled in **Step 8.1** upright.
  - 8.3 : Secure partition (4) to vertical rail (16) using 2x hex head bolts (M) as shown. Use hex key (T) to turn fitting (M) clockwise to fix.




# Step By Step Assembly Instructions

- Step 9** 9.1 : Attach top front rail (8), bottom front rail (10) and fixed shelf (13) onto right side panel (3) as shown. Ensure cam screws (C) and dowels (E) are aligned correctly with the holes of mating parts before attaching.
- 9.2 : Secure top front rail (8), bottom front rail (10) and fixed shelf (13) to right side panel (3) using 4x cam locks (D) as shown. Use a screwdriver to turn fitting (D) clockwise to fix.

Fitting




D x 4



# Step By Step Assembly Instructions


- Step 10** 10.1 : Attach the structure assembled in **Step 8** onto the structure assembled in **Step 9** as shown. Ensure cam screws (C) and dowels (E) are aligned correctly with the holes of mating parts before attaching.
- 10.2 : Secure top back rail (9) and bottom back rail (11) to right side panel (3) using 2x cam locks (D) as shown. Use a screwdriver to turn fitting (D) clockwise to fix.
- 10.3 : Secure partition (4) to fixed shelf (13) using 2x cam locks (D) as shown. Use a screwdriver to turn fitting (D) clockwise to fix.
- 10.4 : Secure partition (4) to bottom front rail (10) using 1x hex head bolt (M) as shown. Use hex key (T) to turn fitting (M) clockwise to fix.



# Step By Step Assembly Instructions

- Step 11** 11.1 : Attach left side panel (2) onto top front rail (8), top back rail (9), bottom front rail (10) and bottom back rail (11) as shown. Ensure cam screws (C) and dowels (E) are aligned correctly with the holes of mating parts before attaching.
- 11.2 : Secure left side panel (2) to top front rail (8), top back rail (9), bottom front rail (10) and bottom back rail (11) using 4x cam locks (D) as shown. Use a screwdriver to turn fitting (D) clockwise to fix.

Fitting



# Step By Step Assembly Instructions

- Step 12**
- 12.1 : Attach top panel (1) onto left & right side panel (2) & (3). Ensure SV fitting system dowels (A), cam screws (C) and dowels (E) are aligned correctly with the holes of mating parts before attaching.
- 12.2 : Secure top panel (1) to left & right side panels (2) & (3) using 4x SV fitting system grub screws (B) as shown. Use a screwdriver to turn fitting (B) clockwise to fix.
- 12.3 : Secure top panel (1) to partition (4) using 2x cam locks (D) as shown. Use a screwdriver to turn fitting (D) clockwise to fix.
- 12.4 : Secure top panel (1) to top back rail (9) using 2x hex head bolts (L) as shown. Use hex key (T) to turn fitting (L) clockwise to fix.


Fitting



B x 4




D x 2



L x 2




T x 1



# Step By Step Assembly Instructions


- Step 13** 13.1 : With help of an assistant, carefully stand the unit upright.  
13.2 : Secure 3x back panels (15) onto back side of the unit using 66x round head screws (Q) as shown. Use a screwdriver to turn fitting (Q) clockwise to fix.

Fitting



# Step By Step Assembly Instructions

- Step 14** **Note:** This product is heavy, it should be assembled as near as possible to the point of use.
- : With help of an assistant, carefully lift the triple wardrobe top upwards over the triple wardrobe base.
  - : Carefully lower triple wardrobe top onto triple wardrobe base. Ensure the holes under triple wardrobe top are aligned correctly with the mating spring pins on triple wardrobe base to avoid damage as shown.




# Step By Step Assembly Instructions

**Step 15** : Secure triple wardrobe top to triple wardrobe base by screwing 4x round head screws (R) into the pre-drilled holes on left & right side panels (2) & (3) as shown. Use a screwdriver to turn fitting (R) clockwise to fix.

Fitting



R x 4





# Step By Step Assembly Instructions

**Step 16** : Attach left & right doors (5) & (6) to left & right side panels (2) & (3) using 8x hex head bolts (N) as shown. Ensure the holes on doors (5) & (6) are aligned correctly with the mating spring pins on left & right side panels (2) & (3) to avoid damage. Use hex key (T) to turn fitting (N) clockwise to fix.


Fitting



N x 8



T x 1




# Step By Step Assembly Instructions

**Step 17** : Attach right door (6) to partition (4) using 4x hex head bolts (N) as shown. Ensure the holes on door (6) are aligned correctly with the mating spring pins on partition (4) to avoid damage. Use hex key (T) to turn fitting (N) clockwise to fix.


Fitting



N x 4




T x 1



# HINGE ADJUSTMENT INSTRUCTIONS


## LATERAL ADJUSTMENT

by screw adjustment.




## FRONT-TO-BACK

by slackening and retightening the hinge-arm mounting screw.



## VERTICAL ADJUSTMENT


via slots on mounting plate by slackening and retightening the screws on mounting plate



# Step By Step Assembly Instructions

- Step 18** 18.1 : Insert 12x wood shelf supports (J) into the pre-drilled holes onto right side panel (3) and partition (4) as shown.
- 18.2 : Tilt wood shelves (14) to a suitable angle as shown in the picture so as to slide them in.
- 18.3 : Slide wood shelves (14) into the unit. Ensure the holes on shelves are facing down, then place them onto the pins of wood shelf supports (J) as shown.

Fitting




# Step By Step Assembly Instructions

- Step 19** 19.1 : Attach 3x knob (K) to the front of doors (5) and (6) using 3x round head bolts (O) as shown. Use a screwdriver to turn fitting (O) clockwise to fix.
- 19.2 : Place cloth bars (G) and (H) onto wood support cloth bars (F) on left & right side panels and partition of unit as shown.
- 19.3 : Attach 9x hinge cover cap (U) onto all hinge arms. Push to clip on as shown.

Fitting



G x 1



H x 1




K x 3



O x 3




U x 9




# TANDEM RUNNER ADJUSTMENT INSTRUCTION

## REMOVE




Extend the runner all the way out.  
Unlock by pulling the black plastic peg on the runner out.



Hold runners with both of your hands.  
Carefully lift the drawer front up from the front metal pin, then slide forward to remove from back hooks.



## VERTICAL ADJUSTMENT ( $\pm 2.5$ mm)



# TANDEM RUNNER ADJUSTMENT INSTRUCTION


## ASSEMBLE

Back hook




Extend the runner all the way out. Put the drawer onto them then hold both the runners with your hands, lift the drawer up with your thumbs and push to hook the drawer at the end of the runner.

Hole / Front metal pin





Hole / plastic peg



Once the back hook is connected gently lower the drawer onto the front metal pin.

Black plastic peg



Lock it by pushing the black plastic peg on the runner in.



# TIP KIT INSTRUCTIONS

## **Notice:**

**Notice:** To prevent injury and property damage from unexpected tipping of furniture, we highly recommend installation of the anti-tip kit included with this product.

### Attaching furniture to wall with anti-tip kits

1. Determine where the piece is to be placed and mark location on the wall for the mounting bracket screw holes. They should be placed approximately 1" below the top on the back of the piece of furniture.
2. Attach the mounting bracket vertically to the wall by inserting the long screws provided through the holes in the bracket and tightening securely using screwdriver. Screws must penetrate wall studs for proper installation.
3. Next using the short screws attach the 2nd bracket to the back of the piece of furniture's top.
4. Lace the nylon strap down through the brackets. Slide the thin end of the strap through the receiving end on the nylon strap. Pull to tighten the piece of furniture snug against wall.



XSTECH - Technical\PRODUCT FILES\ADAMS CHOC- WBSIT ELM134 ABSTIP KIT\ip Its Instructions.JPG

## **CARE INSTRUCTIONS:**

1. Hardware may loosen overtime. Periodically check that all connections are tight.
2. Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.



---

# Care and Maintenance

## Wood Furniture

Wood displays different grain patterns depending on which way they are cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood.

Some furniture is also deliberately aged and rustic.

Wood veneers also allow distinctive patterns to be created on some surfaces, such as table tops and drawer fronts by the way slivers are arranged.

All timber and veneer surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

## How to care for your wood furniture

Dust with a clean, damp, lint free cloth. Frequent dusting will remove abrasive build up, which can damage the finish over time.

Do not use a very wet cloth or allow any liquid to contact with the veneers for a long period of time as this can permanently damage the surface. Wipe up spills immediately.

Do not use any abrasive cleaner or harsh detergent as this can damage the surface of the furniture.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface when building up over time.

Make sure all surfaces are protected from heat and liquids by mats and coasters.

Ensure that a mat or pad is placed under paper when you are writing on the furniture surface.

Do not place rubber or plastic materials on the wood finish as chemicals within may react with the finish if left in contact for an extended period of time.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by home heating can cause damage such as warping, cracking or splitting.

Excessive exposure to sunlight can cause fading of your furniture.

## Safety Instructions:

Never drag furniture when moving it. Always lift it.

Periodically check all fixings to ensure none have come loose. Re-tighten when necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly assembled. Assembly should be carried out by a competent person.

No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

## Heavy item warning:

It is recommended to seek assistance when moving a heavy object. Take care when lifting to avoid personal injury and (or) damage to the product.

It is recommended that before moving a heavy object to a new location it is completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fitting when doing this.

**PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE**