


# 135CM & 150CM SLATTED BEDSTEAD

Stock number: 2807-53/54

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.




## Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

**Necessary Tools :** Pozi screwdriver and Phillips screwdriver




Pz 2 or Pz 3



Ph 2



( Included )



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.


This product takes approximately **50 MINUTES** to assemble with **3 PEOPLE**.

All assembly should be performed on a flat, stable, clean and soft surface.










This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product

The fitting pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

**IMPORTANT:** Retain these instructions for future reference.



## Fittings and parts checklist

Item	Description	Qty.	Item	Description	Qty.
1	Headend	x 1	6	Wood support leg	x 4
2	Footend	x 1	7	Leg	x 4
3	Left side rail	x 1	8	Adjustable metal center leg	x 1
4	Right side rail	x 1	9	Slat frame	x 2
5	Metal center rail	x 1			
A	Bracket 	x 2	F	Grub screw M8 x 8mm 	x 20
B	Hex head bolt M6 x 12mm 	x 4	G	Hex head bolt M6 x 20mm 	x 4
C	Steel dowel Ø7 x 72.5mm 	x 4	H	Hex head bolt M8 x 50mm 	x 2
D	Steel dowel Ø7 x 52mm 	x 16	K	Plug 	x 8
E	Allen key M4 x 30 x 110mm 	x 1			

# Step By Step Assembly Instructions

## Step 1

- 1.1 : Lay all parts on a flat, stable, clean and soft surface.
- 1.2 : Attach 2x brackets (A) onto the pre-drilled holes on headend (1) and footend (2) using 4x hex head bolts (B) as shown. Use allen key (E) to turn fittings (B) clockwise to fix as shown.
- 1.3 : Attach 4x steel dowels (C) onto left & right part (1) by screwing fittings (C) into the inset fittings that are located on part (1) as shown. Use a pozi screwdriver to turn fittings (C) clockwise to fix.
- 1.4 : Attach 8x steel dowels (D) onto headend (1) & footend (2) by screwing fittings (D) into the inset fittings that are located on parts (1) & (2) as shown. Use a pozi screwdriver to turn fittings (D) clockwise to fix.

Fitting



A x 2



B x 4




C x 4



D x 8



E x 1



Step 1.4

# Step By Step Assembly Instructions

- Step 2**
- 2.1 : Attach 8x steel dowels (D) onto side rails (3) & (4) by screwing fittings (D) into the inset fittings that are located on parts (3) & (4) as shown. Use a pozi screwdriver to turn fittings (D) clockwise to fix.
- 2.2 : Attach wood support legs (6) onto side rails (3) & (4) as shown. Ensure steel dowels (D) are aligned correctly with the holes of mating parts before attaching.
- 2.3 : Secure parts (6) to parts (3) & (4) using 8x grub screws (F) as shown. Use a allen key (E) to turn fittings (F) clockwise to fix.

Fitting




D x 8



F x 8



E x 1



**Step 2.1**

**Step 2.3**

**Step 2.2**

**Step 2.2**


**Step 2.2**

**Step 2.2**

**Page : 5**

# Step By Step Assembly Instructions

**Step 3** : Screw legs (7) into the fitting that is concealed in the pre-drilled hole on the wood support legs (6) as shown.



# Step By Step Assembly Instructions

**Step 4** 4.1 : With help of assistant, stand footend (2) upright. Carefully attach footend (2) onto both ends of side rails (3) & (4) as shown. Ensure steel dowels (D) are aligned correctly with the holes of mating parts before attaching.

**Note: Make sure "THIS SIDE UP" labels that are located on wood supports of both side rails (3) & (4) are facing up as shown.**

4.2 : Secure part (2) to parts (3) & (4) using 4x hex head bolts (G) as shown. Use a allen key (E) to turn fittings (G) clockwise to fix.


Fitting



G x 4



E x 1



# Step By Step Assembly Instructions


- Step 5** 5.1 : With help of assistant, stand headend (1) upright and lift up. Carefully attach headend (1) onto both ends of side rails (3) & (4) as shown. Ensure steel dowels (C) & (D) are aligned correctly with the holes of mating parts before attaching.
- Fitting
- 5.2 : Secure part (1) to parts (3) & (4) using 4x grub screws (F) as shown. Use a allen key (E) to turn fittings (F) clockwise to fix.
- 5.3 : Secure parts (1) & (2) to part (6) using 8x grub screws (F) as shown. Use a allen key (E) to turn fittings (F) clockwise to fix.



F x 12



E x 1






# Step By Step Assembly Instructions

- Step 6**
- 6.1 : Remove the bracket from adjustable metal center leg (8) by using allen key (E) to turn 2x hex head bolts counterclockwise as shown.
- 6.2 : Place adjustable metal center leg (8) onto metal center rail (5) then secure the bracket back onto metal center leg (8) using the previously removed 2x hex head bolts as shown. Use allen key (E) to turn bolts clockwise to fix.
- 6.3 : Place the assembled metal center rail (5) with metal center leg (8) onto the brackets (A) that are already affixed on headend (1) and footend (2) as shown.

Fitting



E x 1



# Step By Step Assembly Instructions

- Step 7** 7.1 : Secure part (5) to parts (1) & (2) using 2x hex head bolts (H) as shown. Using allen key (E) to turn fittings (H) clockwise to fix.  
7.2 : Adjust the adjustable center leg to fit with the floor level as shown.

Fitting




H x 2




E x 1

**Step 7.1**




**Step 7.2**



**Adjustable center leg**

## Step By Step Assembly Instructions

**Step 8** Spread out slat frame (9) and place slat frame (9) on the fully structure assembled in step 7 as shown.




# Step By Step Assembly Instructions

**Step 9** Secure slat frame (9) into the pre - drilled holes on supports of side rails (3) & (4) and pre - drilled holes on center rails (5) by using 8x (K) plugs as shown.

Fitting



K x 8




Assembly is complete

---

## CAUTION: To Relocate Bed

---



CAUTION: DO NOT PULL ON SIDE RAIL



CAUTION: LIFT TO RELOCATE BED

ECR# 46077

Luc  
02.10.24

Hung  
02.10.24

  
02/10/24